

Kennedy Series Bench Assembly.

1. Place your new **Benchpro**TM workbench on top of a table with the cardboard seam facing up. Open the carton. don't remove the cardboard yet.



2. Position the legs. If you have a lot of benches to do, we recommend two man teams. If you have Static Control benches, make certain the wrist strap jack is on the front side of the leg.



3. Insert a bolt with a lock washer into each leg.



4. Tighten until lock washer is flat. It doesn't have to be tighter than that.



5. If you ordered drawers or CPU holder, assemble them next.

6. Turn it over. You're done!

