

# Bin Box Rails Assembly

Grant Series

1. After unpacking the bin box bar, slide the T-Head Bolts down the channel in the uprights to the desired position.



2. Have someone hold one end for you.



# Bin Box Rails Assembly

Grant Series

3. Tighten the Nylock fasteners securely.

