

1. Position footrest in preferred position.



2. Insert bolt through footrest, then through frame.



3. Tighten hand knob against tube.

