

Back Mounted Power Strips Assembly

Kennedy, Dewey, Harding & Kennedy Hydraulic Series

1. Install uprights (If any) before the power strips. Center plug strip on back of workbench. Insert screws using an electric drill.

