



- 1) ASSEMBLE 4" FRONT AND BACK RAILS USING STUD PLATES AND LOCK NUTS PROVIDED. BEFORE TIGHTENING NUTS MAKE SURE THAT THE FRONT RAIL AND BACK RAIL ARE FLUSH TO THE TOP OF THE LEG ASSEMBLIES AND PUSHED INWARD APPROXIMATELY 1/8" TO ALLOW THE WORKSURFACE TO BE MOUNTED PROPERLY  
NOTE: HOLES IN RAILS SHOULD BE FACING UP

STOCK NUMBERS

1NX18 - HDL6030SS-H11

1NX22 - HDL7230SS-H11

STAINLESS STEEL HDL

BENCH ASSEMBLY

DRAWING # A7650-SS-PAGE1