

# Lights Assembly

Grant Series

1. Unpack the light fixture. Remove the two lateral adjustment knobs from each end.



2. Attach the two light end brackets to the fixtures with the knobs. Make certain that the T-Head bolts have their heads facing properly to be inserted into the slots of the uprights.



3. With a helper, insert the T-Head Bolts' heads into the slots of the uprights.



4. Tighten the Nylock nuts securely.



## Lights Assembly

Grant Series

5. Plug the cord into the outlet on the top of the upright.

