


1. Position the CPU Holder anywhere on the bottom of the workbench. Insert the screws.



2. Place your computer on the bottom shelf.



3. The CPU holder comes with two nylon mesh straps. Insert them through the sets of holes which best retain your CPU. Pull the end tab to tighten.

